


01 The Delta HLA Plus Device, designed with modern networking needs in mind, is equipped with an Ethernet port to facilitate wired LAN connections. This feature allows you to link the device directly to your router or a multi-port network switch with the use of a Cat5 or Cat6 Ethernet cable. This setup ensures a stable, high-speed internet connection for optimised performance.



02 To establish a connection between your Delta HLA Plus Device and the router or network insert the Ethernet cable.



03 To set up the Delta HLA Plus Device on Ethernet/LAN for the first time. Begin by positioning yourself near/in front of the Delta HLA Plus Device. During the initial setup, the 'COMMS' button of the Delta HLA Plus device will illuminate red. Press and hold the "COMMS" button for 10 seconds. The "COMMS" button will illuminate flashing green. Using your smartphone or other Wi-Fi enabled device (such as a laptop or tablet), search for the Delta HLA Plus Access Point.



04 Once located, connect your smartphone or other Wi-Fi enabled device to the Access Point "Delta HLA Plus". After establishing a connection, open Safari, or any web browser and type **192.168.4.1** into the address bar.



05 Delta HLA Plus Devices offer flexibility in usage. You have the option to use the devices as standalone high-water level alarm without an internet connection. However, for complete access to all notification and monitoring features, connect your Delta HLA Plus Device to the internet.




This can be accomplished either through Wi-Fi or Ethernet, based on your convenience and requirements.

06 On the Delta HLA Plus Access Point choose "use Ethernet".

Then select the "Save" option. You must remember to select "Save".



07 The Delta HLA Plus Device will Reboot. The Delta HLA Plus Device is designed to re-establish connection autonomously upon rebooting. Its functionality is reflected through the COMMS button on the panel front that illuminates a steady green, thereby signifying an active Internet connection.



08 Once the Delta HLA Plus Device has rebooted. The Delta HLA Plus local page will offer detailed information about the Delta HLA Plus Device, including its connection status. You can also check the Delta HLA Plus Device's status on the Delta Pumps App (after the Device has been Registered to a User Account).

